

How to install TF card into Sunba IP camera?

Step 1. Loosen 4 screws located on the back cover. You don't necessarily need to remove all of the 4 screws to take out the back cover.



Note

Please do NOT remove this mini slot on the back of the camera, which is reserved for engineer's examination purpose.



Step 2. Take out the black back cover.



Step 3. Locate the TF Card Slot, and insert the TF Card.

